

FIRST ON THE WATER

NRS ALLEY CAT FRAME

Components:

- (2) Yokes
- (4) Side Rails
- (1) Cross Bar
- (1) Seat Bar
- (1) Foot Bar
- (1) Pair Oar Mounts
- (1) Pair of Cooler Mounts
- (1) Frame Wrench
- (16) U-bolts
- (32) Washers and Locking Nuts
- (1) High-back padded seat with bolts and washers

Note: Side Rails, Cooler Mounts and Seat are packaged separately.

Directions:

- 1. Lay out the frame parts as shown in the image above. Place the yokes upside down with the narrow end up.
- Install U-bolts on the inner yoke LoPros. Add the washers and the nuts, leaving them loose. Slide the two inner side rails in through the U-bolts, then tighten the nuts.
- 3. Turn the yoke right side up so that the inner rails are supporting the frame. Follow step 2 with the outer rails.
- 4. Set the seat, foot, and cross bars in place and add the U-bolts, nuts and washers leaving them loose. Be sure that the side marked "Front" on the seat bar faces forward. Adjust the crossbars so that they fit against the cooler or dry box snugly. If any of the bars need to be repositioned, it may be necessary to remove the U-bolts to make adjustments.
- 5. Add seat, cooler mounts, and oar mounts.

o. Add oddi, oddioi inidanio, and ddi inidanio.

6. Check to be sure that all of the U-bolts are tight. Periodically check the tightness of all nuts and bolts.

2009

S. Main Street

Moscow, ID 83843

800-635-5202

www.nrsweb.com