
Fantasea Line

Light Shielding Pad SEL16F28 (Cat. No. 2301)

Instruction Manual

The **Light Shielding Pad SEL16F28** was designed for the **Sony SEL16F28** lens when used inside housings featuring the Fantasea FML port system. The Light Shielding Pad blocks the output of light sources inside the housing from reflecting on the lens and dome. For housings and lenses compatibility information, please visit the Fantasea website – www.fantasea.com



SPECIFICATIONS

- Material: Sponge and Polycarbonate
- Dimensions (diameter x height): 78 x 8 mm / 3.1 x 0.3 inch
- Weight: 2 g / 0.07 oz
- Manufacturer's warranty

INSTRUCTIONS FOR USE

1. Mount the **Sony SEL16F28** lens on the camera.
2. If mounting a converter over the **SEL16F28** lens, mount it only after installing the Lighting Shielding Pad over the lens.
3. Remove the lens cap.
4. Hold the Light Shielding Pad against the lens so that the soft spongy side of it faces the lens.
5. Install the Light Shielding Pad on the lens by sliding it from the front of the lens towards the camera body until reaching a point of minimal resistance.
6. If mounting a converter over the lens, it can be mounted once the Lighting Shielding Pad has been installed.
7. Follow the housing instruction manual to install the camera inside the housing.
8. When removing the camera from the housing, the Lighting Shielding Pad might become separated from the lens and remain inside the housing due to the friction between the Lighting Shielding Pad and the lens port. Make sure to remove the Light Shielding Pad from the housing in order to avoid losing it.

CARE & MAINTENANCE

1. Please use the utmost care and do not use excessive force when assembling and disassembling the different parts, in order not cause any damage to the products.
2. Keep the Lighting Shielding Pad away from extreme high temperatures, as under direct sunlight.
3. Keep the Lighting Shielding Pad away from water in order to prevent deformation of the product.
4. Do not clean the Lighting Shielding Pad with any chemical solvents or other materials.
5. When storing the Lighting Shielding Pad and during transportation, make sure that it is properly protected in order to prevent deformation of the product.
6. Do not store the Lighting Shielding Pad in presence of chemicals, solvents or fuels.



FANTASEA PRODUCT CONSUMER LIMITED WARRANTY

“Fantasea” warrants this Fantasea Line branded product against defects in materials and workmanship under reasonable use for a period of ONE (1) YEAR, (two years, where required by law as determined by the origin of the authorized dealer). This warranty is effective from the date of retail purchase from Fantasea or an authorized Fantasea dealer, by the original end-user purchaser (“Warranty Period”). This warranty does not cover any commercial use of the product. If a product defect arises and a valid claim is received within the Warranty Period, at its option, Fantasea, or its authorized service facilities will either (1) repair the product defect at no charge, (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. The warranty will not extend beyond the original warranty period. Your Fantasea Product should be registered within 30 days of purchase. You must keep the proof of purchase which indicates the date on which the purchase was made; as you may be required to show proof of purchase if you need warranty service. The following conditions apply:

1. This warranty extends to the original purchaser only. It is not assignable or transferable.
2. The warranty does not cover damage resulting from misuse, abuse, negligence, or accidents. Proper maintenance of the Product is the responsibility of the owner.
3. The warranty does not cover damage directly or indirectly resulting from the use of unauthorized replacement parts or service performed by unauthorized facilities.
4. This warranty does not cover any damage to any other product used in conjunction with the Fantasea product, including cameras and lenses, and resulting from any defect in the product materials or workmanship.
5. The cost of sending the product back to Fantasea or its authorized service facilities is the responsibility of the customer.
6. The warranty does not cover any incidental damages resulting from any defects in the product. This expressly includes any travel reimbursements or any other costs associated with the purchaser’s optional use of the product.

The conditions of this warranty are expressly in lieu of all other expressed warranties, including the payment of consequential or incidental damages for the breach of any warranty. Please register your product on line at this URL: <http://www.fantasea.com/registration>.

For further information, please contact us at info@fantasea.com or visit our website www.fantasea.com