

ULTRALIGHT SONIC BARK CONTROL

QUICK GUIDE

Read training manual and quick guide before attempting to use the product.



STEP 1

BATTERY ACTIVATION

The battery module is installed in your UltraLight Sonic Bark Control unit. A removable protective film on the contact side of the battery prevents activation of the unit. Introduce your dog to the bark control unit as described in the training manual before removing the protective film.

To remove the battery, insert a coin in the slot on top of the battery module, push down slightly and turn counter-clockwise. Flip battery to contact side. To remove the protective film, lift the red tab and peel off the film.

To re-install battery, align the arrow on the battery module with the triangle on the unit. Using a coin, push down and turn clockwise, until the arrow on the battery module lines up with the "Lock" on the unit.


Battery life is dependent on the number of corrections your dog receives, but on average the life should be 1 month.



STEP 2

TEST UNIT

Hold your finger over the speaker to muffle the sound when testing the unit. Blow across the microphone. The unit should emit a sharp sound. If you do not hear a tone – check the battery and repeat the test.



STEP 3

SET MICROPHONE SENSITIVITY LEVEL




Locate the microphone High/ Low switch on the side of the unit. Begin with the setting in the low position. If the unit does not emit a sound correction when the dog barks, move the switch to the high setting.

STEP 4

ATTACH TO COLLAR

Note: Do not place unit on your dog without reading the Training Manual.

Collar material thickness should be approximately 1/16", and no wider than 1". Slide the collar under all four clips. Be sure the unit is placed in the center of the collar, opposite of the buckle, and fits snugly against the middle of the dog's throat. The microphone may not activate properly if the unit is rotated to the side or if the collar hangs too loosely. Remove any tags from the collar to avoid triggering a false stimulation.



STEP 5

OBSERVE FIRST REACTION

Observe your dog's first reaction to the correction. As excited as your dog may get, you must remain calm. Yelping or cowering is a normal response. Your pet must clearly understand the reason for the stimulation in order to change his behavior. Modifying your dog's barking behavior may take several days.

Each dog will need different lengths of time to learn to control their nuisance barking.

CAUTIONS

To prevent damage to the inner ear, do not place the unit next to your ear, the ear of any other human, or your pet's ear.

Keep out of the reach of children.

Do not allow dog to chew on unit.

Unit is not waterproof - do not immerse in water.

If unit gets wet, you may remove battery, shake out excess water, and let unit dry before attempting to use again.

ADDITIONAL INFORMATION

If you have additional questions regarding this product or training, U.S. customers may contact PetSafe Customer Support at 1-800-732-2677. The phones are staffed Monday – Friday 8AM till 7PM, Saturdays 9AM till 5PM, and Sundays 1PM till 5PM (Eastern Time).

Correspondence may be sent to the following address:

Radio Systems Corporation
10427 Electric Ave.
Knoxville, TN 37932

Other helpful information may be found on our website:

www.petsafe.net

RETURNS

If you are experiencing problems with your unit, our customer support department may be able to offer helpful advice. Should you decide to return your product, please include a brief description of the problem and ship to: RSC, Service Warehouse, 10427 Electric Ave., Knoxville, TN, 37932. You pay the shipping charges to RSC. RSC pays the shipping charges to return to you.