

MobiShow Client for Windows Mobile

User's Manual

Version: 1.0

Date: Nov.08, 2011

1.1 Install MobiShow Client

1.1.1 Download from WPS box


- 1) Turn on WiFi on your phone.
- 2) Connect your phone to MobiShow wireless network. The SSID is displayed on screen
- 3) Open the browser on your phone and enter the IP address of the MobiShow box.
 - ◆ The default IP address is 192.168.100.10.
 - ◆ Or, refer to the IP address which shown on the projector screen.
- 4) Click the "Download" link to download the software installer (in CAB format) to your phone.
- 5) Open Explorer on your phone and find the CAB file.
- 6) Double click on the CAB file to start installation.
- 7) Follow on-screen instructions to finish installation.

1.1.2 Install MobiShow Client by USB Token


- 1) Find the MobiShow_WM5.cab in USB Token.
- 2) Connect your phone and laptop by USB connecting line and copy the MobiShow client to phone.
- 3) Double click on the CAB file to start installation.
- 4) Follow on-screen instructions to finish installation.

1.2 Using MobiShow with a Smartphone

- 1) Open "Programs" on your phone and find "MobiShow" application.
- 2) Select "MobiShow" icon  to launch the client software.
- 3) MobiShow will turn on Wi-Fi on your phone and list available access points for you to choose.



- 4) Select a MobiShow wireless network (SSID with prefix MobiShow) to connect to.
- 5) MobiShow client will connect to that access point and search for MobiShow devices automatically. When a MobiShow device is found, it will automatically login and the following main menu is shown on your phone.



- If more than one MobiShow devices are found, the following list will be displayed for you to select the one to use.




1) Select which feature to use. To project the screen of your phone, click on the "Screen" icon. To do a PC-less presentation with Presentation-to-Go (PtG), select the "PtG" icon. To play a video or MP3 from your phone, select the "Media" icon.

- Screen Projection:

MobiShow will project anything displayed on your screen. You may launch another application (such PowerPoint Viewer) or open any file (such as Word document or JPG image) and it will be projected to the projector.

Note: Do not exit MobiShow application while opening other application to keep screen projected.



Click the "Stop" icon to stop projection.

Click the "Pause" icon to pause projection. Click "Pause" again to resume projection.

Click the "Zoom" icon to zoom the projected screen to extend the longest side of your screen to fill the screen.

Click the "Play" icon to start projection again if it is stopped.

Click the "OK" button or "Back" to return to main menu.

- Wireless PtG:

When you select PtG function, MobiShow client will automatically open Explorer for you to select a PtG file. Select the file to open for your

presentation. When the file is open, the PtG slides will be projected, and the following screen is displayed on your phone for you to control your PtG presentation.

You need to use "PtG converter.exe" to convert Powerpoint become PtG file first. You can find out "PtG converter.exe" in the USB Token



Click "Prev" or "Next" to go to the previous or next item in the slide.

Click "PgUp" or "PgDn" to go to previous or next slide.

Click "Stop" to stop projecting the file. The icon will become "Play" if the file is not played. Click "Play" again to play the file if it is stopped.

Click "Home" to go to the first slide.

Click "Jump" and MobiShow client will show every slide on the phone. You can select any page to go to.

Click "Open" to select another PtG file.


Note:

You may find PtG converted in the USB Token for your testing.

- Photo Slideshow:

You can use MobiShow to project photos stored on your phone to big screen. The photos will be prepared for playback on big screens rather than for the tiny screens of your phone.

To open a single photo, select one photo and click the OK button. The photo will be displayed on the display connected to MobiShow device.



Click "Prev" or "Next" to go to the previous or next photo in the same folder.

Click "Play" to start photo slideshow with photos in the same folder. The button will be changed to "Pause" during slideshow. Click "Pause" to stop slideshow.

- Media Sender:

When you select Media Sender function, MobiShow client will automatically open Explorer for you to select a media file. Select a file (videos in mpeg or wmv9 format, or MP3 music files) to play. The file will be streamed to MobiShow device. It may take a few seconds to buffer before the playback begins, depending on the wireless signal and media bit rate.



When the file is open, the media will be projected, and the following screen is displayed on the phone for you to control your media playback.

Click "FR" or "FF" to seek backward or forward.

Click "Vol-" or "Vol+" to adjust volume for playback.

Click "Stop" to stop playing the file. The icon will become "Play" if the file is not played. Click "Play" again to play the file if it is stopped.

Click "Mute" to mute the audio. Click "Mute" again to bring audio back.

Click "Open" to select another media file.

- 2) When you are in the main menu, click the "OK" button or "Back" again to close the application.