


SNMP Management Feature Description

WPS device equip the SNMP management feature to make the device management easier. By enabling the SNMP (Simple Network Management Protocol) protocol (Version 2c), the device could be managed and configured through network. Besides, the WPS SNMP manager is designed to provide the device management for each device and the advanced batch configuration feature to configure the bunch of WPS devices at the same time.

SNMP Manager – Quick Guide:

Discovery:

Install the SNMP manager and launch the application, it should discover the WPS device automatically.



1. Browse and Configure:


Browse and configure the system properties without accessing the web admin page.

There are two modes of using:

1. Simple Mode (default)
2. Advanced Mode

Simple Mode


You can click the items in left to modify the settings of your devices




- ❖ For the “Read only” item, the column of new value input area is disabled.
- ❖ For the “Read/Written” item, you could modify the setting for a bunch of devices at the same time.

Advanced Mode

If you want to modify the advanced settings for single device, please choose “File/Advanced Mode”




Choose one of the connected devices, you could see all detailed information in right side.



2. Import or Export:


You can use "Load Configuration" function to import a configuration file, or "Save Configuration" function to export a configuration file for saving the device configuration.




PS: This function is for advanced mode only.

3. Batch Configuration:

Configure a bunch of devices by using the same configuration file.



Choose devices:



Press "OK" to save the settings for the devices you select.