

Metals - Old Part Number Conversion Chart

Old Part #	Trombetta Phase 1 Number	New Trombetta #
91224-1	91224	934-1212-210-02
91224-2	91224	934-1212-210-02
92426-1	98420-WR	974-2411-611
97210-1	97210	934-1254-610
97216-1	97216-BR	935-1225-010-13
97220-1	97220-WR	934-1215-611
97220-3	97220	934-1215-610-09
97220-6	97220-X	904-1243-610-11
97226-3	97226	934-1215-010-09
97226-4	97226-WR	936-1215-011-21
97240-2	97240	934-1215-010-16
97240-3	97240	934-1243-610-15
97240-4	97240-X	904-1243-610-15
97416-1	97416-BR	935-2425-010-14
97426-1	97426-02	934-2462-010-22
97440-1	97440-X	904-2443-610-15
97440-2	97440	934-2443-610-15
98126-1	98126	976-0615-010
98214-2	98214-WR-BR	974-1235-211-12
98216-1	98216-BR	975-1225-010-13
98216-3	98216-WR-BR	974-1235-011-12
98220-10	98220	976-1211-610-07
98220-4	98220	974-1215-610-09
98220-6	98220	974-1215-610-09
98220-8		974-1215-611
98224-2	98224	974-1215-210
98224-3	98224	974-1215-211
98226-10	98226-WR	974-1215-011
98226-12	98226	976-1215-010
98226-14	98226-WR	974-1215-011-11
98226-18	98226	976-1211-010
98226-19	98226	974-1215-010
98226-22	98226-WR	974-1215-011-30
98226-23	98226-WR	974-1215-011-30
98226-25	98226	974-1215-010
98226-26	98226	974-1215-010
98226-27	98226-WR	974-1215-011
98226-29	98226-WR	974-1215-011
98226-4	98226-WR	974-1215-011
98226-6	98226	974-1215-010-09
98226-9	98226-WR	974-1215-011-09
98240-2	98240	974-1215-610-16
98240-3	98240	974-1243-610-15
98240-5	98240-WR	974-1215-611-18
98240-6	98240	974-1215-610-19
98290-3	98290-WR	977-1225-611-18
98290-4	98290-WR	977-1225-611-18
98416-1	98416	976-2425-010-09
98420-5		974-2415-611

98420-7	98424	974-2411-210-07
98424-1	98426-02	974-2411-010-31
98426-1	98426	974-2415-010
98426-10	98426	986-2415-010-09
98426-10	98426	986-2415-010-21
98426-13	92426	974-2412-011-04
98426-18	98240-WR	974-1243-611-15
98426-19	98426	974-2415-010
98426-2	98426	974-2415-010
98426-9	98426-66	989-2415-010-27
98429-1	98429	978-2413-020
98440-1	98446	974-2415-010-28
98440-2	98440	974-2443-610-15
98440-3	98440-WR	974-2415-611-16
98440-4	98440-WR	974-2415-611-18
98490-7	98490-WR	977-2425-611-28
98526-3	98926	974-3015-010
98526-6	98526	986-3615-010-09
98526-6	98526	986-3615-010-21
98926-3	98440-WR	974-2443-611-15
	91424	934-2412-210-01
	92426	974-2412-010-01
	98426	974-2413-010-32
	98426	974-2415-010-05
	98446-CWP	974-2415-010-19
	98426-WR	974-2415-011-06
	98440	974-2415-610-23
	98526	974-3613-010-10
	98626-WR	974-4815-011
	98220-WR	976-1211-611
	98426-02-WR	976-2415-011-25
	98426-66	989-2415-010-09
	98526-66	989-3615-010-09
	98526-66	989-3615-010-21