Parts of WCR683DZD-2

Item	Parts No.	Description	Qty
1	DG11-4	DRY FILTER	1
2	DG2-11	POWER CORD	1
3	DG12-22	CONNECTION PIPE	1
4	DG13-1	WATER TRAY	1
5	DG13-24	SHOCKPROOF BLOCK	1
6	DG1-76	COMPRESSOR	1
7	DG17-25	COMPRESSOR GROUNDING LINE	1
8	DG17-93	COMPRESSOR GROUNDING LINE	1
9	DG12-112	SEAL PIPE	2
10	DG22-302	POWER BOARD	1
11	DG3-1050.2	PCB	1
12	DG6-1003.1	TRANSFORMER	1
13			1
14	DG22-1062	LEFT UPPER HINGE	1
15	DG3-1012.1	LED BOARD	2
16	DG13-1079	MAIN BOARD COVER	1
17	DG22-1096	S/S FRONT INSERT	3
18	DG22-1063	RIGHT UPPER HINGE	1
19	DG22-1064	DOOR AXIS	1
20	DG12-59	EVAPORATOR	1
21	DG8-8-R	DEFROST SENSOR	1
22	DG7-1008.1	EVAPORATOR FAN	1
23	DG7-4.5-W	HEATER FAN	1
24	DG18-80	HEATER FOAM	2
25	DG14-24	HEATER INSULATION BOARD	1
26	DG11-1.1	HEATER	1
27	DG22-1184	AIR-DUCT BOARD A	1
28	DG13-247	FAN WATER-BLOCK BOARD	1
29	DG8-10-Y	SENSOR	1
30	DG13-198	SENSOR COVER	2
31	DG19-6	FAN COVER	1
32	DG19-2	FAN COVER	1
33	DG22-1022.2	UPPER MIDDLE AIR-DUCT BOARD	1
34	DG18-1043	MIDDLE AIR-DUCT FOAM	1
35	DG18-1046	MIDDLE AIR-DUCT FOAM 1	1
36	DG22-314	AIR-DUCT BOARD C	1
37	KT-057	MIDDLE AIR-DUCT BOARD STRIP	1
38	DG22-1020.1	SHELF ROLLER	13
39	DG15-501.1	SHELF (TOP)	6
40	DG13-1013	S/S FRONT INSERT INCLUDING CONTROL PANEL FILM	1
41		GASKET	1
42	DG14-506	LOCK	1
43	DG23-1071.7	DOOR	1
44	DG14-1014	LOWER DOOR HINGE AXIS	1
45	DG14-1029.7	HANDLE	1
46	DG15-1002	SHELF (LOWER)	1
47	DG15-502	SHELF	1
48	DG15-501	SHELF (TOP)	7
49	DG22-1021	12-INCH ROLLER	1
50	DG13-7	SHELF SUPPORT	2
51	DG13-1049	LED LIGHT COVER	1
52	DG7-3.1	FAN	1
53	DG13-1063	CHARCOAL FILTER	1
54	DG22-1009.1	BOTTOM GRILLE	1
55	DG8-10-W	SENSOR	1
56	DG13-10	AIR-DUCT WATER TANK	1
57	DG18-63	EVAPORATOR FOAM	2
58	DG14-508.1	RIGHT LOWER HINGE	1
59	DG13-6.1	CABINET LEG	4
60	DG22-240	SUPPORT BRACKET OF FRONT LEGS	1
61	DG12-3	CONDENSOR	1
62	DG12-55	AIR-CIRCULATING PIPE IN UPPER ZONE	1
63	DG22-254	COMPRESSOR BRACKET	1
64	DG7-23	OUTSIDE FAN	1
65	DG14-56	OUTSIDE FAN BRACKET	2
66	DG19-3	FAN COVER	1
67	FL-107	DRAIN PIPE	1


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
67
66
65
64
63
62
61
60
59
58
57
56
55
54
53
52
51
15
50
49
48
47
46
45
44