Hand Grip Strap for Camera Housings (TypeF)



Catalog No. 11188

Instructions for Assembly:

Frame 1 and 2

Pull narrow nylon Velcro strip through top of lower housing Ring (below the locking latch) in a downward direction to the end of the strip.

Frame 3

Place wide, flat Velcro mid-section over the locking latch and pull the thin Velcro strip over the top of this mid-section and through the upper housing ring from bottom to top all the way through.

Frame 4

Double back the thin nylon Velcro strip and secure it tight to the top of the Velcro strip previously inserted (same strip) and press down. Then cover with the wide flap (should be on the right side) over the thin Velcro strips.

Frame 5 and 6

Close Place top flap (with logo) over bottom flap and press to close.













Instructions for Use:

To use, slide right hand from back side to front of the Hand strap with knuckles protruding slightly out of the front (lens side) of the strap. Have it snug but not too tight to allow for control manipulation.

Always use the wrist lanyard with the hand strap.

When opening or closing the housing, you may need to loosen the hand strap slightly in order to rotate it forward to allow for easier opening and closing of the latch.

When closing the housing, take special notice and care not to close part of the hand strap inside the housing which will cause flooding of the housing and the camera.

Please make sure to rinse the wrist strap in fresh water and then dry after every use. Store in a dry, shaded area or closed room.